

Setting Up Your NatureZap Pro

Charging your NatureZap Pro:

Only use the NatureZap Pro battery charger supplied by Global Neighbor Inc.

1. Plug the battery charger connector into the battery charger port on the NatureZap Pro.
 2. Plug the battery charger into an electrical AC outlet inside a building or one that is protected from outside elements. Read "Safety Information" section for other cautions.
- The status light on the charger will illuminate RED when charging and GREEN when fully charge. The charger will charge your battery overnight. When fully charged, disconnect the charger from the NatureZap Pro to avoid over charging.

The battery is designed to retain a full charge for several months. If the charger has been disconnected for several weeks after being charged, the battery will still have a full charge.

TIP: Charge the NatureZap Pro battery before storing for an extended period of time.

This will help extend the life of the battery.

How to fill your NatureZap Pro:

After charging the NatureZap Pro

1. Remove the cap of the Steam Boost water chamber.
2. Pour approx. 2 cups of tap water into the water chamber.
3. Replace the cap of the Steam Boost water chamber.

Safety Information

As with all power tools and heating devices, please follow all safety precautions when using this tool. Be sure to read, understand, and follow all instructions in this guide. Be sure to store this guide in a convenient place so that you can access it easily if you have questions about operating this tool. If you have any questions about the safe use of this tool, please contact Global Neighbor, Inc. by phone at 937.285.0990, by email at support@g-neighbor.com, or by using the link on our website (www.g-neighbor.com).

CAUTION: HAZARD OF BURN



To reduce the risk of injury, burns, or fire:

- DO NOT touch the heated surface of this tool to bare skin. It can reach temperatures up to 400 °F (200 °C).
- DO NOT touch the heated surface of this tool to fabrics. It can cause certain fabrics to catch on fire or to melt.
- DO NOT store this tool until it cools.
- DO NOT store this tool near flammable or combustible materials.

CAUTION: HAZARD OF ELECTRICAL SHOCK



To reduce the risk of injury or death by electric shock:

- DO NOT use this tool in the rain or if rain and/or lightning are possible.
- DO NOT disassemble this tool. No user-serviceable parts are inside.
- DO NOT use this tool if the battery charger adapter cord is damaged.
- DO NOT leave this tool plugged in if you are not using it.

CAUTION: GENERAL HAZARDS



To reduce the risk of personal injury or damage to the tool:

- DO NOT allow children to handle this tool.
- DO NOT touch the sharp tip of this tool to bare skin. It can puncture skin.
- DO NOT operate this tool with bare feet or open sandals.
- DO NOT store this tool in a location where it could get damp/wet.

Maintenance and Care Storage

Allow this tool to cool before storing it.

Empty any excess water from the Steam Boost water chamber before storing.

Store this tool away from flammable or combustible materials.

Store this tool out of the reach of children.

Store this tool in a dry location.

Store this tool in an upright position. It can be hung from a hook or firmly attached to a wall. The handle is capable of holding the weight of the tool.

Specifications:

Wattage 250 W

Charger: Current 110 V, 60 Hz, 5 Amps max

Warm-Up Time 3 minutes

Auto Shutoff 40 minutes

Operating Temperature 400 °F (200 °C)

Recycling Information

Global Neighbor, Inc. is committed to environmental stewardship. In an effort to protect and preserve global resources, we have designed NatureZap Pro so that it can be recycled. For more information about how to do this, please contact us by visiting our website (www.g-neighbor.com), sending an e-mail (support@g-neighbor.com), or calling us (1.937.285.0990).

Limited Two-Year Warranty

NatureZap Pro, the thermogenic weed control tool, is warranted for two (2) years against defects in materials or workmanship when used for personal residential lawn and garden care.

For the purposes of this warranty, "personal residential garden and lawn care" refers to non-commercial residential use and further excludes misuse, accidents, or damages due to inadequate maintenance.

Global Neighbor, Inc. certifies that NatureZap Pro is fit for ordinary purposes for which a product of this type is used. Global Neighbor, Inc., however, limits the implied warranties of merchantability and fitness to two (2) years for personal residential garden and lawn care.

The Limited Two-Year Warranty on NatureZap Pro starts on the day of purchase. The Limited Two-Year Warranty is applicable only to the original owner. The owner is responsible for performing all the required maintenance as defined by the manufacturer's user guide. Attachments and accessories to the tool are not covered by this warranty.

During the warranty period, the warranty holder is responsible for any and all shipping charges if required. Some states do not allow limitations on the length of implied warranties, so the above limitations may not apply to you.

Global Neighbor, Inc. shall not be liable under any circumstances for any incidental or consequential damages or expenses of any kind, including but not limited to, cost of equipment rentals, or cost of hiring services to perform tasks normally performed by this tool. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

Global Neighbor, Incorporated

Phone: 1.937.285.0990

Website: www.g-neighbor.com

E-mail: support@g-neighbor.com

© 2010, Global Neighbor, Incorporated. All rights reserved.

Global Neighbor, Inc., the Globe and Hands logo, and NatureZap Pro are trademarks of Global Neighbor, Incorporated, registered in the United States Patent and Trademark Office. (December 2010)



Global Neighbor
INCORPORATED